



WHEN FIGURING OUT WHAT LENGTH THE SUMPS SHOULD BE, YOU'LL NEED TO DO THE FOLLOWING BEFORE CUTTING.

1. BEFORE BACK FILLING TO THE TOP OF THE SUMP PUT THE RISER REDUCER & TOP HAT ON AND FIGURE 12" FROM (A) TO (B) TO TOP OF GRADE ON TOP HAT LID.
2. TRIM PIPING SUMP TUBE, NOT TOP HAT OR REDUCER TO ADJUST HEIGHT AS NEEDED.
3. BELLOWS ADJUSTMENT IS 2" TO BE CUT SHORTER.

(SAFEWAY SPECS.)